









# ASSEMBLING INSTRUCTION

**SHIRO TV RACK 120**

WHITE - TUSCANY OAK



<p>010801</p>  <p>8 X</p>	<p>010701</p>  <p>8 X</p>	<p>010501</p>  <p>28 X</p>	<p>011402</p>  <p>12 X Ø10 MM X 1 3/4"</p>	<p>011601</p>  <p>4 X Ø6 MM X 1 1/2"</p>	<p>011704</p>  <p>16 X Ø6 X 1/2"</p>
<p>011707</p>  <p>16 X Ø6 X 5/8"</p>	<p>020305</p>  <p>4 X</p>	<p>060136</p>  <p>2 X</p>	<p>100905</p>  <p>2 X</p>	<p>100901</p>  <p>2 X</p>	<p>011002</p>  <p>12 gr</p>



 X 1 ± 60 M 

010701



8 X

011601



4 X

010501



4 X

010501




6 X

011402




8 X


1



2



3



05


06

010501




12X

011402



4X

100905



2X

100901



2X

011707



16X

Ø10 MM X 1 3/4"

Ø6 X 5/8"

010501




6X

010801




8X


4



5




6



011704

020305

060136




Ø6 X 1/2"

16 X

4 X

2 X

7




09

011002




12 gr

8



9



10