













ASSEMBLING INSTRUCTION

SHIRO SHOE RACK 80


WHITE - TUSCANY OAK




161001  4 X	050701  16 X	010501  22 X	011402  17 X	090201  2 X	011704  8 X
090401  1 X	020202  2 X	091002  1 X	011707  18 X	020101  4 X	011001  2 gr
011002  6 gr	100901  2 X	100907  2 X			




010501	011402	011704	090201	020101	161001
2X	1X	8X	2X	4X	4X



010501	011402	011707	090401
12X	10X	4X	1X



100907



2 X

010501



8 X

100901



2 X

011402




6 X

011707




14 X

6



7




050701





16 X


8





9



10



11



12

