
















ASSEMBLING INSTRUCTION


KUVA SHOWCASE 2DF



 E1 Ø 15 MM X 12 MM 24 X	 D Ø 6 MM X 32 MM 24 X	 B Ø 8 MM X 30 MM 31 X	 J3 Ø 12 MM X 1 3/4" 16 X	 M3 Ø 6 MM X 1 1/2" 28 X	 M Ø 4 MM X 1 1/2" 2 X
 M1 Ø 4 MM X 5/8" 16 X	 G 16 X	 A5 Ø 4 MM X 10 MM 2 X	 S 8 X	 V 2 X	 AE1 16 X
 BT16 4 X	 BU 1 X	 AY 1 X	 BP1 1 X	 AA1 WHITE 3 M	 BR1 1 X
 BS 1 X	 AN1 2 X				


 X 2  ±45 M

03




04

1




2




2X

07

3




4




08


6




7




8




9



10




11




12

11


13



14




15




12


16



17




18





2X


19




20




21



22




23




2X

24




25




17

26



27



18