




ASSEMBLING INSTRUCTION

SHIRO RSG 4DK

WHITE - TUSCANY OAK



011402



12 X

010501



22 X

100901



2 X

020101



8 X

011002



12 g

090701




4 X

060210



4 X

030201



4 X

011704



Ø6 X 1/2"


20 X

011707



Ø6 X 5/8"



12 X





X 2



±60 M







<p>090701</p>  <p>4 X</p>	<p>060210</p>  <p>4 X</p>	<p>030201</p>  <p>4 X</p>
<p>011002</p>  <p>12 g Ø6 x 1/2"</p>		<p>011704</p>  <p>20 X</p>

5

7



6

07

08